

HOW TO E-CLEAN

“E-CLEAN a minimum of every 2 weeks or twice a month”.


- Power off, then unplug the machine



- Unlock (turn left) the filter ring lock and remove HG filter



- Always check the O-ring and place back on HG filter



- Put 1(one) sachet of e-clean powder in CPU – (cleaning portable unit).



- Install the CPU then lock, turn ring to the right to install



- Turn on the faucet. When the water starts to flow from the flex hose, count to 10 and then turn off the faucet.
- Place the flex hose & grey hose in a glass. Allow the water to partially fill the glass.



- Leave the flex hose and grey hose for 4 to 5 hours.
- Remove the glass, arrange the hoses, turn on the faucet and let the water run for 5 minutes.
- Remove CPU, unscrew and let dry. Place HG filter and lock into place (turn right).



- Plug machine in, turn power on, e-clean is complete.

Enagic Philippines Inc.

**6788 Ayala Avenue
Makati Sky Plaza Bldg. Makati City
Tel: 519 5508 / 659 5035
Fax: 519 1923**